




ART 4TH/G+



USER MANUAL


INDEX

1. System operation	3
1.1. Call reception	3
1.2. In communication	3
1.3. Make a call	3
2. Home screenl	4
3. Functions	4
3.1. “Do Not Disturb” menu	4
3.2. Events	4
3.3. Preview	6
3.4. Intercom	6
4. Settings	7
4.1. Personal	7
4.2. About	8
4.2. System	8


1. SYSTEM OPERATION

1.1 Call reception:

When receiving a call the monitor starts beeping displaying on the screen who is trying to communicate with the house. The monitor will automatically take a snapshot so that if the call is not answered, you can check who the caller was.




1.2. In communication:




1.3. Make a call:

To start a call with other device in the installation select from the home screen  .
 Make the call via the contact book:




EDIT CONTACT BOOK



(*) It is possible to do a call rapidly to the guard unit. To do so, simply press  from the home screen.

2. HOME SCREEN



(*)QUICK ACCESS ICONS:


Icons located on the bottom row of the screen are quick access. To be able to use them the corresponding function must be enabled and in some cases have an additional element (guard unit, lift controller, alarm sensor...).

3. FUNCTIONS



3.1. "Do not disturb" menu.

This function allows to manage the behaviour of the monitor when a notification occurs.




(*) When "Automatic door open" mode enabled, the monitor will automatically open the door without the need of responding the call from the door panel.



3.2. Events.

The events section provides the following options:



These are defined in detail below:



Picture recordings, shows the snapshot log.

Picture recordings				01/03
● 001001	Peter Night	22-08-2020	23:00	
001801	Lobby entrance	12-08-2020	11:55	
001003	Tom Berry	28-07-2020	07:40	
002801	Parking entrance	04-07-2020	13:15	
001851	Concierge	30-06-2020	18:20	

Panel from which the snapshot was made.

Date and time when it was produced.

Shown snapshot.

Back to the previous screen.

Move through the various picture recordings.

Snapshot display

Display the previous or next snapshot.

Individual deletion from snapshot, press and confirm .

Back to the previous screen.



Video recordings, shows the video recordings log.

Video recordings				01/03
● 001001	Peter Night	22-08-2020	23:00	
001801	Lobby entrance	12-08-2020	11:55	
001003	Tom Berry	28-07-2020	07:40	
002801	Parking entrance	04-07-2020	13:15	
001851	Concierge	30-06-2020	18:20	

Panel from which the video was made.

Date and time when it was produced.

Shown recording.

Back to the previous screen.

Move through the various video recordings.

Display the previous or next recording.

Individual deletion from snapshot, press and confirm .

Back to the previous screen.

Play the video.



Missed calls, shows the log of unanswered incoming calls:

Call ID	Name	Date	Time
001001	Peter Night	22-08-2020	23:00
001801	Lobby entrance	12-08-2020	11:55
001003	Tom Berry	28-07-2020	07:40
002801	Parking entrance	04-07-2020	13:15
001851	Concierge	30-06-2020	18:20

Panel from which the call was made.

Date and time when it was produced.

Back to the previous screen.

Delete lost call.

Move through the various lost calls.



Messages, displays received messages.

Message ID	Sender	Date	Time
001891	South guard	22-08-2020	23:00
001001	Peter Night	12-08-2020	11:55
001003	Tom Berry	28-07-2020	07:40
001852	North guard	04-07-2020	13:15
099901	Site guard	30-06-2020	18:20

Origin of the message.

Date and time when it was produced.

*Alarm message. IMPORTANT: When receiving an alarm message, the monitor will alert of that on screen and in a sonorous way.

Back to the previous screen.

Delete message.

Read message.

Move through the various messages.

001851 South guard 22-08-2020 23:00

Hello. This is Peter.

Back to the previous screen.

Delete message.

Show the previous or next message.



3.3. Preview.

Preview the images from the door panels and cameras registered in the system.

Panel Name	Panel Name
North entrance	North entrance
South entrance	South entrance
Lobby entrance	Lobby entrance
Parking entrance	Parking entrance
Parking entrance	Parking entrance

Move through the different door panels.

Access to registered cameras list.

Back to the main screen.

Preview door panel images.

Move through the different cameras.

Access to door panels list.

Back to the main screen.

Preview camera images.



3.4. Intercom.

To see how to intercom with the monitor, go to the “Make a call” manual section.

4. SETTINGS



Settings.

The settings section provides the following options:



These are defined in detail below:



4.1. Personal: melody selection, volume, leave message...



User.

Move through the fields.

Language selection.

Identification name of the monitor. (the name modification is not instantaneous, it updates at midnight)

Set the code of panel opening. *The code cannot be repeated or consecutive. Example: 8888 or 1234 would not be valid

Back to the previous screen.



Ringtones.

Move through the fields.

Adjust ringtone volume between 1-5.

Select ringtone between 1-6. (selecting different ringtones allow to differentiate the origin of the call)

Back to the previous screen.

Choose the field to be modified.



Leave message.

Enable Leave message.

Move through the fields.

Start time.

End time.

Interval in which it will be enabled.


Instant activation or if the call is not answered.

Back to the previous screen.

Choose the field to be modified.



Reset personal settings.




Back to the previous screen

Reset all personal settings.




4.2. About: Device information.



Back to the previous screen

Access to the manual QR code.



Back to the about section.



4.3. System: Installer settings.

“System” settings are not detailed in this manual as these are installer settings.



C/ Silici 13. Poligon Industrial Famadas
08940 – Cornellà del Llobregat – Spain
golmar@golmar.es
Telf: +34 934 800 696
www.golmar.es